




TOYOTA HIACE LWB, 06/19 on



TOPLINE MOUNT

PART NUMBER: VAS.TLR15



Note:

- PLEASE READ INSTRUCTIONS AND CHECK CONTENT PRIOR TO INSTALLING.
- PLACE INSTRUCTIONS IN VEHICLES GLOVE COMPARTMENT AFTER INSTALLING.



Maximum capacity: 120kg

Tested to AS/NZS 1235-200 ADR standards

- Please check your vehicle's manual for vehicle load capacity (please do not exceed the lowest load rating) and please download and read our Load Rating guide which can be found on our website vas.com.au.
- Load rating is based on driving on sealed roads to road conditions and includes weight of roof rack system.

Important information

- Complete maintenance checks weekly including bolt connections and tightness.
- Heavy loads carried near feet
- Overhanging loads should conform to relevant state laws
- Check tie down strap tension every 50klm as loads can shift
- Specialised equipment carriers such as ladder slides should be used
- Ensure your roof racks, ladder rails and or load does not inhibit the tailgate lifting on vehicles manufactured with these doors
- Check car park heights before entering
- Keep load under the maximum capacity
- Use non stretch fastening straps
- Remove roof racks prior to using an automatic car wash

Note: The handling characteristics of a vehicle will change when a carrier system is fitted. Driving technique such as speed reduction, cornering techniques and braking distances should be altered to allow for these changes.



Kit Inclusions

Item	Part Description	4 Bar
1	Right Rail (Hiace) - C272R	1
2	Left Rail (Hiace) - C272L	1
3	M8 x 25 socket HD Cap screw - F048	12
4	M8 x 17 Flat washer - F017	12
5	M8 Spring Washer - F018	12
6	M10 x 20mm Hex Bolt - F024	8
7	M10 x 21 Flat washer - F032	8
8	M10 Spring Washer - F034	8
9	M10 Channel Nut - F035	8

Tools Required

- A - Cleaning cloth.
- B - Ball end allen tool.
- C - 17mm socket wrench.
- D - 10mm socket wrench.
- E - Butyl mastic sealant.



Note:
Platform (as
separate).



Step 1

A - Locate the 6 black metal roof brackets (3 per side), on the roof of the vehicle.



B - Using a 10mm socket, carefully remove each bracket. You must alternate loosening the bolts progressively to ensure mounts are not dislodged on the inside of the vehicle.



Step 2


A - Clean and dry the roof.

B - Apply butyl mastic to the exposed threads in the roof.





Step 3

Slide the M8 hardware through the slots in the rail, as shown.




Step 4

Place the rail onto the roof. The M8 hardware in the rail will fix to the exposed threads in the roof. Tighten with a ball end allen key to 8-10Nm.




Step 5

Install the M10 hardware as shown. Be sure to orientate the channel as below, this will allow the crossbar to slide over the top.




Step 6

Place the crossbars onto the rails. Make sure the crossbars are evenly spaced. Ensure the channel nut is across the crossbar as shown.



Step 6

Use a 17mm socket or ring spanner, to fix the crossbars in place to 14-16Nm.



Note

Place the crossbars onto the installed Topline. Fix in place with the M6 hardware provided and tighten with an allen key. **Thoroughly check all fasteners are secure before driving away. Heights are for standard unloaded vehicles. Always check your specific vehicles height.**

